



ECOBX PVC

Technical Schedule

CONTAINER FOR POLLUTING SUBSTANCES (ACIDS)

- Produced in PVC, equipped with a device for liquid level checking. When liquids go over the present limit it makes a float go up and a hummer work. It is possible to install a warning light and an automatic electric exhaust-valve on request. That device can work even in the opposite way, that is setting a minimum level under which the device begins humming.
- External dimensions : (LxPxH) mm 450x400x410 h
- Weight: kg. 4
- Capacity 42 litres